











COM







IC-F21S Toggle type radio

Perfect for Business, Big or Small

The on-site communications solution

For small business, hotels, hospitality, landscape, nursery, etc. who need economical and instant two-way communications. Also a wireless intercom solution for large retailers, warehouses, etc.

Keep in touch without interruption

Keep all your associates in-touch instantly without the interruption of a public address system or the expense and complication of a cell phone. Answer customer inquiries, check stock, arrange special handling, and provide better service to your customers right from the retail sales floor. Increase productivity at the same time you improve service.

Twice as much power than other models

Use a full 5/4 watts when you need it, or select a lower setting if you don't ... you decide. Increase the range of your transmissions out-doors, and indoors where obstacles and walls offer challenges to your current equipment. Crystal clear communications.

Simple controls, easy to use

Transmit button, volume control and channel selector are all you need. All three controls may be operated without removing from your belt. The perfect business tool that doesn't require training to use. Great for high turnover or retail shift situations.

Military rugged construction

Don't let the light weight or compact body fool you. This is a military spec. rugged radio that can take abuse and keep working. Don't worry about special training. Just put them out in the workplace and let them do their job.

Wide/narrow capability - a good investment

May be operated on 12.5 or 25kHz wide channels. Easy transition to the new narrow channels as regulations will move in that direction in several years. A good investment that will adapt to the future. Won't be obsolete as the rules change.

Multiple group and individual selective calling

Use the built-in signaling capability (2-tone, 5-tone, CTCSS, DTCS) to set up your own talk groups and quiet the radio when others are talking. You can set up selective calls to individuals too. Keep private communications private and eliminate unnecessary interruptions and gossip in the workplace.

Other features

- Compact and lightweight carry all day with no fatigue
- Ni-Cd battery and drop-in battery charger* included
- (* depending on versions) • Optional speaker mic, VOX headset, and much more
- Optional alkaline or Ni-MH battery pack



IC-F21 Rotary type radio

IC-F11/S·IC-F21/S

SPECIFICATIONS

GENERAL						
• Frequency coverage (MHz)						
İC-F	11/IC-F11S	: 146–174				
IC-F	21/IC-F21S	: 400–430 440–470				
 Channe 	l spacing	:12.5/25 kHz				
Number of channels		: 16 (rotary type)				
		4 (toggle type)				
 PLL channel step 		: 2.5kHz, 3.125kHz (VHF)				
		5kHz, 6.25kHz (UHF)				
 Power supply requirement 		nt:7.2V DC				
 Current 	drain (approx.)					
Тx	High (5W/4W)	: 1.6A				
Rx	Rated audio	: 250mA				
	Standby	: 70mA				
 Frequer 	ncy stability	: ±5ppm (VHF), ±2.5ppm (UHF)				
 Operatir 	ng temperature rai	nge :				
	-30°C	C to +60°C ; –22°F to +140°F				
 Dimensions (W×H×D) 		:54×128×37 mm				
(proj. not	included)	; 21⁄8×51⁄32×115⁄32 in				
Weight (with BP-209)		: 310g; 10.9oz				

TRANSMITTER							
Output power (at 7.2V DC)	: 5W, 2W or 1W (VHF) 4W, 2W or 1W (UHF)						
Max. frequency deviation	:±5.0kHz (at 25kHz) ±2.5kHz (at 12.5kHz)						
Spurious emissions	:73dBc typ.						
Adjacent channel power	:70dB typ. (at 25kHz) 60dB typ. (at 12.5kHz)						
External mic. connector	: 3-conductor 2.5 (d) mm						

•External mic. connector :3-conductor (1/10")/2.2kΩ

RECEIVER

Sensitivity	: 0.25µV typ. (at 12dB SINAD)
 Squelch sensitivity 	: 0.3µV typ. (at threshold)
 Adjacent channel selectivity 	:70dB typ. (at 25kHz)
	65dB typ. (at 12.5kHz)
 Spurious response rejection 	:70dB typ.
 Intermodulation rejection 	:70dB typ. Me

 Audio output power (at 7.2V DC)

•External speaker connector

: 500mW (typical at 5% distortion with an 8Ω load) : 2-conductor 3.5 (d) mm (1/8")/8 Ω

Supplied accessories:						
 Battery pack; BP-209 Antenna (varies from versions) AC adapter; BC-147* 	Belt clip; MB-68 Battery charger; BC-146* * depending on version					
Annella shire in O. Milliana One si Gasariana						

Applicable U.S. Military Specifications

Standard	MIL 810 C		MIL 810 D		MIL 810 E		MIL 810 F	
Stanuaru	Method	Proc.	Method	Proc.	Method	Proc.	Method	Proc.
Low Pressure	500.1	I	500.2	I, II	500.3	I, II	500.4	I, II
High Temp.	501.1	I	501.2	I, II	501.3	I, II	501.4	I, II
Low Temp.	502.1	I	502.2	I, II	502.3	I, II	502.4-3	I, II
Temp. Shock	503.1	I	503.2	I	503.3	Ι	503.4	I
Solar Radiation	505.1	I	505.2	I	505.3	I	505.4	Ι
Rain	506.1	I, II	506.2	I, II	506.3	I, II	506.4	I, II
Humidity	507.1	I, II	507.2	II, III	507.3	II, III	507.4	-
Salt Fog	509.1	I	509.2	I	509.3	I	509.4	-
Dust	510.1	I	510.2	I	510.3	I	510.4	I
Vibration	514.2	VIII, X	514.3	Ι	514.4	I	514.5	Ι
Shock	516.2	I, II, V	516.3	I, IV	516.4	I, IV	516.5	I, IV

Measurements made in accordance with EIA-152-C/204D or TIA-603. All stated specifications are subject to change without notice or obligation.

OPTIONS





HM-46L: Slim dimensions. Equipped with an earphone jack and a transmit indicator. HM-75A: Allows you to remotely select operating channel, etc., according to program. HM-131L: Compact and durable body. Equipped with an earphone jack and a revolving clip.

HM-128L:Light weight earphone-mic. Compact microphone with PTT Switch clips to your lapel. THS-94 HS-95 HS-94: Earhook headset with flexible boom microphone.

- HS-95: Behind-the-head headset with flexible boom microphone.
- HS-97: Throat microphone fits aroud your neck and picks up a speech vibration.
- VS-1L: PTT/VOX unit. Required when using these headsets with the transceiver.

HS-51: Headset HS-51 is also optionally available. Includes VOX, PTT and "onetouch" PTT with a time-out timer. (UHF only in U.S.A. and Canada)

ICOM Inc. 1-1-32, Kamiminami, Hirano-ku, Osaka 547-0003, Japan Phone: 06 6793 5302 Fax: 06 6793 0013 URL: http://www.icom.co.jp/world/index.html

Count on us!

Icom America Inc.

<Corporate Headquarters> 2380 116th Avenue N.E., Bellevue, WA 98004, U.S.A. Phone: (425) 454-8155 Fax: (425) 454-1509 URL : http://www.icomamerica.com <Customer Service> Phone : (425) 454-7619

Icom Canada

Glenwood Centre #150-6165 Highway 17, Delta, B.C., V4K 5B8, Canada Phone : (604) 952-4266 Fax : (604) 952-0090 URL : http://www.icomcanada.com

Icom (Australia) Pty. Ltd. A.B.N. 88 006 092 575 290-294 Albert Street, Brunswick, Victoria, 3056, Australia Phone: 03 9387 0666 Fax: 03 9387 0022 URL :http://www.icom.net.au

Icom New Zealand 146A Harris Road, East Tamaki, Auckland, New Zealand Phone: 09 274 4062 Fax: 09 274 4708 URL : http://www.icom.co.nz Icom (Europe) GmbH

Communication Equipment Himmelgeister Str. 100, D-40225 Düsseldorf, Germany Phone: 0211 346047 Fax: 0211 333639 URL : http://www.icomeurope.com

Icom Spain S.L. Crta. de Gracia a Manresa Km. 14,750 08190 Sant Cugat del Valles Barcelona, SPAIN Phone: (93) 590 26 70 Fax: (93) 589 04 46 URL : http://www.icomspain.com

Icom (UK) Ltd.

Unit 9, Sea St., Herne Bay, Kent, CT6 8LD, U.K. Phone : 01227 741741 Fax : 01227 741742 URL : http://www.icomuk.co.uk

Icom France S.a

Zac de la Plaine, Rue Brindejonc des Moulinais BP 5804, 31505 Toulouse Cedex, France Phone: 561 36 03 03 Fax: 561 36 03 00 URL : http://www.icom-france.com Asia Icom Inc. 6F No. 68, Sec. 1 Cheng-Teh Road, Taipei, Taiwan, R.O.C. Phone: (02) 2559 1899 Fax : (02) 2559 1874 URL : http://www.asia-icom.com

Your local distributor/dealer:



Icom Inc. (Japan), is an ISO9001 certification acquired company.

DC power supply (12–20 V DC). **SP-13** EARPHONE Provides clear audio in noisy environment.

STUBBY ANTENNAS

BNC-type antenna.

MB-68 BELT CLIP Same as that supplied.

(For maintenance use only) MB-74 BELT CLIP Alligator type.

OPC-656 DC POWER CABLE

For use the BC-121N with a

FA-SC56VS: 146–162MHz, 80mm FA-SC57VS: 160–174MHz, 80mm FA-SC73US: 450–490MHz, 60mm